


Article information - SET1113, TIMKEN Wheel Bearing

Manufacturer	TIMKEN	
Article number	SET1113	
Description	Wheel Bearing	
Trade numbers	33213	
Status	Normal	
Packing unit	1	
Quantity per packing unit	1	
GTIN/EAN		

Criteria

Width [mm]	41
Outer Diameter [mm]	120
Inner Diameter [mm]	65
Weight [kg]	1.92

Documents



Axle linkages

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
SAF - RBM - RBM 8442				- 8400		3032
Fitting Position outer						
SAF - RBM - RBM 8442/12						
Fitting Position outer				- 8400		3035
SAF - RLBM - RLBM 8442				- 8400		3186
Fitting Position outer						
SAF - RLBM - RLBM 8442/12						
Fitting Position outer				- 11000		3189
SAF - RLBM - RLBM 8442				- 8400		3192
Fitting Position outer						
SAF - RLBM - RLBM 8442/12						
Fitting Position outer				- 11000		3038
SAF - RSM - RSM 11242				- 8400		3048
Fitting Position outer						
SAF - RSM - RSM 8442						
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
SAF - RSM - RSM 8442-8				- 8400		3051
Fitting Position outer						
SAF - RZM - RZM 11242				- 11000		3058
Fitting Position outer						
SAF - RZM - RZM 8442				- 8400		3069
Fitting Position outer						
SAF - RZM - RZM 8442-8				- 8400		3072
Fitting Position outer						
SAF - WRLZM - WRLZM 11030				- 11000		3199
Fitting Position outer						
SAF - WRLZM - WRLZM 11035-10				- 11000		3201
Fitting Position outer						
SAF - WRLZM - WRLZM 11035-8				- 11000		3203
Fitting Position outer						
SAF - WRLZM - WRLZM 8130				- 8100		3205
Fitting Position outer						
SAF - WRLZM - WRLZM 8435-10				- 8400		3207
Fitting Position outer						
SAF - WRLZM - WRLZM 8435-8				- 8400		3209
Fitting Position outer						
SAF - WRZM - WRZM 11242				- 11000		3081
Fitting Position outer						
SAF - WRZM - WRZM 8442				- 8400		3090
Fitting Position outer						
SAF - WRZM - WRZM 8442-8				- 8400		3093
Fitting Position outer						
BPW - H - HI 10000				- 10000		1964
Fitting Position outer						
BPW - H - HI 11000				- 11000		1965
Fitting Position outer						
BPW - H - HI 12000				- 12000		1966
Fitting Position outer						
BPW - H - HI 12000-16				- 12000		1967
Fitting Position outer						
BPW - H - HIZ 10000				- 10000		2012
Fitting Position outer						
BPW - H - HIZ 11000				- 11000		2013
Fitting Position outer						
BPW - H - HIZ 12000				- 12000		2014
Fitting Position outer						
BPW - H - HIZ 12000-16				- 12000		2015
Fitting Position outer						
BPW - H - HIZD 10000				- 10000		2025
Fitting Position outer						
BPW - H - HIZD 11000				- 11000		2026
Fitting Position outer						
BPW - H - HIZH 11000				- 11000		2027
Fitting Position outer						
BPW - H - HIZH 12000				- 12000		2028
Fitting Position outer						
BPW - H - HIZH 12000-16				- 12000		2029
Fitting Position outer						
BPW - H - HIZOR 10000				- 10000		2036
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HIZOU 10000-1 D36				- 10000		2037
Fitting Position outer						
BPW - H - HIZVB 10000 K				- 10000		2039
Fitting Position outer						
BPW - H - HIZVB 12000 K				- 12000		2040
Fitting Position outer						
BPW - H - HIZVBQ 12000 K				- 12000		2042
Fitting Position outer						
BPW - H - HIZVBU 10000 K				- 10000		2043
Fitting Position outer						
BPW - H - HIZW 2/10000				- 10000		2044
Fitting Position outer						
BPW - H - HIZW 2/11000				- 11000		2045
Fitting Position outer						
BPW - H - HIZW 2/11000 K				- 11000		2046
Fitting Position outer						
BPW - H - HIZW 2/12000				- 12000		2047
Fitting Position outer						
BPW - H - HIZW 2/12000 B				- 12000		2048
Fitting Position outer						
BPW - H - HS 10010				- 10000		2049
Fitting Position outer						
BPW - H - HS 11010				- 11000		2050
Fitting Position outer						
BPW - H - HS 11010-16				- 11000		2051
Fitting Position outer						
BPW - H - HS 12010				- 12000		2052
Fitting Position outer						
BPW - H - HS 12010 7/8 IN				- 12000		2053
Fitting Position outer						
BPW - H - HS 12010-16				- 12000		2054
Fitting Position outer						
BPW - H - HSF 10010				- 10000		2080
Fitting Position outer						
BPW - H - HSF 10010 ECO				- 10000		2081
Fitting Position outer						
BPW - H - HSF 10010 ECO-MAXX				- 10000		2082
Fitting Position outer						
BPW - H - HSF 10010-15				- 10000		2083
Fitting Position outer						
BPW - H - HSF 10010-15 ECO				- 10000		2084
Fitting Position outer						
BPW - H - HSF 10010-15 ECO Plus				- 10000		2085
Fitting Position outer						
BPW - H - HSF 10010-15 ECO-MAXX				- 10000		2086
Fitting Position outer						
BPW - H - HSF 10110-15				- 10000		2087
Fitting Position outer						
BPW - H - HSF 10110-15 ECO				- 10000		2088
Fitting Position outer						
BPW - H - HSF 10110-15 ECO Plus				- 10000		2089
Fitting Position outer						
BPW - H - HSF 10110-15 ECO-MAXX				- 10000		2090
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HSF 11010				- 11000		2091
Fitting Position outer						
BPW - H - HSF 11010 ECO				- 11000		2092
Fitting Position outer						
BPW - H - HSF 11010 ECO Plus				- 11000		2093
Fitting Position outer						
BPW - H - HSF 11010 ECO-MAXX				- 11000		2094
Fitting Position outer						
BPW - H - HSF 11010-15				- 11000		2095
Fitting Position outer						
BPW - H - HSF 11010-15 ECO				- 11000		2096
Fitting Position outer						
BPW - H - HSF 11010-15 ECO Plus				- 11000		2097
Fitting Position outer						
BPW - H - HSF 11010-15 ECO-MAXX				- 11000		2098
Fitting Position outer						
BPW - H - HSF 11010-16				- 11000		2099
Fitting Position outer						
BPW - H - HSF 12010				- 12000		2100
Fitting Position outer						
BPW - H - HSF 12010 ECO				- 12000		2101
Fitting Position outer						
BPW - H - HSF 12010 ECO PLUS				- 12000		2102
Fitting Position outer						
BPW - H - HSF 12010 ECO-MAXX				- 12000		2103
Fitting Position outer						
BPW - H - HSF 12010-16				- 12000		2104
Fitting Position outer						
BPW - H - HSF 12010-16 ECO				- 12000		2105
Fitting Position outer						
BPW - H - HSF 12010-16 ECO Plus				- 12000		2106
Fitting Position outer						
BPW - H - HSF 12010-16 ECO-MAXX				- 12000		2107
Fitting Position outer						
BPW - H - HSF 9010 ECO Plus				- 9000		2127
Fitting Position outer						
BPW - H - HSF 9010-15 ECO Plus				- 9000		2133
Fitting Position outer						
BPW - H - HSFH 10010 ECO-MAXX				- 10000		2143
Fitting Position outer						
BPW - H - HSFH 10010-15 ECO				- 10000		2144
Fitting Position outer						
BPW - H - HSFH 10010-15 ECO-MAXX				- 10000		2145
Fitting Position outer						
BPW - H - HSFH 10110-15 ECO				- 10000		2146
Fitting Position outer						
BPW - H - HSFH 10110-15 ECO-MAXX				- 10000		2147
Fitting Position outer						
BPW - H - HSFH 11010				- 11000		2148
Fitting Position outer						
BPW - H - HSFH 11010 ECO				- 11000		2149
Fitting Position outer						
BPW - H - HSFH 11010 ECO-MAXX				- 11000		2150
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HSFH 11010-15 ECO-MAXX				- 11000		2151
Fitting Position outer						
BPW - H - HSFH 11010-16				- 11000		2152
Fitting Position outer						
BPW - H - HSFH 12010				- 12000		2153
Fitting Position outer						
BPW - H - HSFH 12010 ECO				- 12000		2154
Fitting Position outer						
BPW - H - HSFH 12010 ECO-MAXX				- 12000		2155
Fitting Position outer						
BPW - H - HSFH 12010-16				- 12000		2156
Fitting Position outer						
BPW - H - HSFH 12010-16 ECO				- 12000		2157
Fitting Position outer						
BPW - H - HSFH 12010-16 ECO Plus				- 12000		2158
Fitting Position outer						
BPW - H - HSFH 12010-16 ECO-MAXX				- 12000		2159
Fitting Position outer						
BPW - H - HSFH 9010 ECO Plus				- 9000		2167
Fitting Position outer						
BPW - H - HSFH 9010-15 ECO Plus				- 9000		2171
Fitting Position outer						
BPW - H - HSFHLL 10010/12° ECO Plus				- 10000		2174
Fitting Position outer						
BPW - H - HSFHLL 10010/12° ECO-MAXX				- 10000		2175
Fitting Position outer						
BPW - H - HSFHLL 10010/8° ECO-MAXX				- 10000		2176
Fitting Position outer						
BPW - H - HSFHLL 12010/12° ECO Plus				- 12000		2177
Fitting Position outer						
BPW - H - HSFHLL 12010/12° ECO-MAXX				- 12000		2178
Fitting Position outer						
BPW - H - HSFHLL 12010/8° ECO-MAXX				- 12000		2179
Fitting Position outer						
BPW - H - HSFHLL 9010/12° ECO Plus				- 9000		2186
Fitting Position outer						
BPW - H - HSFHLLP 10010/12° ECO-MAXX				- 10000		2190
Fitting Position outer						
BPW - H - HSFLL 10010/12° ECO-MAXX				- 10000		2197
Fitting Position outer						
BPW - H - HSFLL 12010 /12° ECO Plus				- 12000		2198
Fitting Position outer						
BPW - H - HSFLL 12010/12° ECO-MAXX				- 12000		2199
Fitting Position outer						
BPW - H - HSFLL 9010/12° ECO Plus				- 9000		2207
Fitting Position outer						
BPW - H - HSFOM 10010 E36				- 10000		2228
Fitting Position outer						
BPW - H - HSH 10010				- 10000		2250
Fitting Position outer						
BPW - H - HSH 11010				- 11000		2251
Fitting Position outer						
BPW - H - HSH 11010-16				- 11000		2252
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HSH 12010				- 12000		2253
Fitting Position outer						
BPW - H - HSHOT 10010				- 10000		2270
Fitting Position outer						
BPW - H - HSM 10010				- 10000		2285
Fitting Position outer						
BPW - H - HSM 10010 ECO				- 10000		2286
Fitting Position outer						
BPW - H - HSM 10010-15				- 10000		2287
Fitting Position outer						
BPW - H - HSM 10010-15 ECO				- 10000		2288
Fitting Position outer						
BPW - H - HSM 10110-15				- 10000		2289
Fitting Position outer						
BPW - H - HSM 10110-15 ECO				- 10000		2290
Fitting Position outer						
BPW - H - HSM 10110-15 ECO Plus				- 10000		2291
Fitting Position outer						
BPW - H - HSM 11010				- 11000		2292
Fitting Position outer						
BPW - H - HSM 11010 ECO				- 11000		2293
Fitting Position outer						
BPW - H - HSM 11010 ECO Plus				- 11000		2294
Fitting Position outer						
BPW - H - HSM 11010 ECO-MAXX				- 11000		2295
Fitting Position outer						
BPW - H - HSM 11010-15 ECO				- 11000		2296
Fitting Position outer						
BPW - H - HSM 11010-16				- 11000		2297
Fitting Position outer						
BPW - H - HSM 12010				- 12000		2298
Fitting Position outer						
BPW - H - HSM 12010 ECO				- 12000		2299
Fitting Position outer						
BPW - H - HSM 12010 ECO Plus				- 12000		2300
Fitting Position outer						
BPW - H - HSM 12010 ECO-MAXX				- 12000		2301
Fitting Position outer						
BPW - H - HSM 12010-16				- 12000		2302
Fitting Position outer						
BPW - H - HSM 12010-16 ECO				- 12000		2303
Fitting Position outer						
BPW - H - HSM 12010-16 ECO Plus				- 12000		2304
Fitting Position outer						
BPW - H - HSM 12010-16 ECO-MAXX				- 12000		2305
Fitting Position outer						
BPW - H - HSM 12810 ECO				- 12800		2306
Fitting Position outer						
BPW - H - HSM 9010 ECO Plus				- 9000		2323
Fitting Position outer						
BPW - H - HSM 9010-15 ECO Plus				- 9000		2328
Fitting Position outer						
BPW - H - HSMH 10010				- 10000		2342
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HZF 11010				- 11000		2656
Fitting Position outer						
BPW - H - HZF 11010 ECO				- 11000		2657
Fitting Position outer						
BPW - H - HZF 11010 ECO Pus				- 11000		2658
Fitting Position outer						
BPW - H - HZF 11010 ECO-MAXX				- 11000		2659
Fitting Position outer						
BPW - H - HZF 11010-15 ECO-MAXX				- 11000		2660
Fitting Position outer						
BPW - H - HZF 11010-16				- 11000		2661
Fitting Position outer						
BPW - H - HZF 12010				- 12000		2662
Fitting Position outer						
BPW - H - HZF 12010 ECO				- 12000		2663
Fitting Position outer						
BPW - H - HZF 12010 ECO Plus				- 12000		2664
Fitting Position outer						
BPW - H - HZF 12010 ECO-MAXX				- 12000		2665
Fitting Position outer						
BPW - H - HZF 12010-10 ECO Plus				- 12000		2666
Fitting Position outer						
BPW - H - HZF 12010-10 ECO-MAXX				- 12000		2667
Fitting Position outer						
BPW - H - HZF 12010-16				- 12000		2668
Fitting Position outer						
BPW - H - HZF 12010-16 ECO				- 12000		2669
Fitting Position outer						
BPW - H - HZF 12010-16 ECO Plus				- 12000		2670
Fitting Position outer						
BPW - H - HZF 12010-16 ECO-MAXX				- 12000		2671
Fitting Position outer						
BPW - H - HZF 12010-16EG ECO-MAXX				- 12000		2672
Fitting Position outer						
BPW - H - HZF 9010 ECO Plus				- 9000		2683
Fitting Position outer						
BPW - H - HZF 9010-15 ECO Plus				- 9000		2687
Fitting Position outer						
BPW - H - HZFD 11008				- 11000		2692
Fitting Position outer						
BPW - H - HZFD 11010				- 11000		2693
Fitting Position outer						
BPW - H - HZFD 11010-16				- 11000		2694
Fitting Position outer						
BPW - H - HZFD 12010-16				- 12000		2695
Fitting Position outer						
BPW - H - HZFDH 11010				- 11000		2701
Fitting Position outer						
BPW - H - HZFDH 11010-16				- 11000		2702
Fitting Position outer						
BPW - H - HZFH 10010-15 ECO				- 10000		2710
Fitting Position outer						
BPW - H - HZFH 10010-16				- 10000		2711
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HZFH 10110-15 ECO				- 10000		2712
Fitting Position outer						
BPW - H - HZFH 10110-15 ECO Plus				- 10000		2713
Fitting Position outer						
BPW - H - HZFH 10110-15 ECO-MAX				- 10000		2714
Fitting Position outer						
BPW - H - HZFH 11010				- 11000		2715
Fitting Position outer						
BPW - H - HZFH 11010 ECO				- 11000		2716
Fitting Position outer						
BPW - H - HZFH 11010 ECO-MAXX				- 11000		2717
Fitting Position outer						
BPW - H - HZFH 12010				- 12000		2718
Fitting Position outer						
BPW - H - HZFH 12010 ECO				- 12000		2719
Fitting Position outer						
BPW - H - HZFH 12010 ECO Plus				- 12000		2720
Fitting Position outer						
BPW - H - HZFH 12010 ECO-MAXX				- 12000		2721
Fitting Position outer						
BPW - H - HZFH 12010-16				- 12000		2722
Fitting Position outer						
BPW - H - HZFH 12010-16 ECO				- 12000		2723
Fitting Position outer						
BPW - H - HZFH 12010-16 ECO-MAXX				- 12000		2724
Fitting Position outer						
BPW - H - HZFH 9010-15 ECO Plus				- 9000		2733
Fitting Position outer						
BPW - H - HZFLL 12010/12° ECO Plus				- 12000		2738
Fitting Position outer						
BPW - H - HZFLL 12010/12° ECO-MAXX				- 12000		2739
Fitting Position outer						
BPW - H - HZFLL 12010/20° ECO-MAXX				- 12000		2740
Fitting Position outer						
BPW - H - HZFOM 10010 E36				- 10000		2744
Fitting Position outer						
BPW - H - HZH 11010				- 11000		2752
Fitting Position outer						
BPW - H - HZH 12010				- 12000		2753
Fitting Position outer						
BPW - H - HZHOT 10010				- 10000		2760
Fitting Position outer						
BPW - H - HZM 10010				- 10000		2764
Fitting Position outer						
BPW - H - HZM 10010-15 ECO				- 10000		2765
Fitting Position outer						
BPW - H - HZM 10010-16				- 10000		2766
Fitting Position outer						
BPW - H - HZM 10110-15				- 10000		2767
Fitting Position outer						
BPW - H - HZM 10110-15 ECO				- 10000		2768
Fitting Position outer						
BPW - H - HZM 11010				- 11000		2769
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HZM 11010 ECO				- 11000		2770
Fitting Position outer						
BPW - H - HZM 11010 ECO Plus				- 11000		2771
Fitting Position outer						
BPW - H - HZM 11010 ECO-MAXX				- 11000		2772
Fitting Position outer						
BPW - H - HZM 11010-16				- 11000		2773
Fitting Position outer						
BPW - H - HZM 11110-15 ECO				- 11000		2774
Fitting Position outer						
BPW - H - HZM 12010				- 12000		2775
Fitting Position outer						
BPW - H - HZM 12010 ECO				- 12000		2776
Fitting Position outer						
BPW - H - HZM 12010 ECO-MAXX				- 12000		2777
Fitting Position outer						
BPW - H - HZM 12010-16				- 12000		2778
Fitting Position outer						
BPW - H - HZM 12010-16 ECO				- 12000		2779
Fitting Position outer						
BPW - H - HZM 12010-16 ECO Plus				- 12000		2780
Fitting Position outer						
BPW - H - HZM 12010-16 ECO-MAXX				- 12000		2781
Fitting Position outer						
BPW - H - HZM 12810 ECO				- 12800		2783
Fitting Position outer						
BPW - H - HZM 9010-15 ECO Plus				- 9000		2805
Fitting Position outer						
BPW - H - HZMD 10010				- 10000		2812
Fitting Position outer						
BPW - H - HZMD 11008				- 11000		2813
Fitting Position outer						
BPW - H - HZMD 11010				- 11000		2814
Fitting Position outer						
BPW - H - HZMD 11010-16				- 11000		2815
Fitting Position outer						
BPW - H - HZMDH 11010				- 11000		2823
Fitting Position outer						
BPW - H - HZMDHOM 10010				- 10000		2825
Fitting Position outer						
BPW - H - HZMDHOT 10010				- 10000		2826
Fitting Position outer						
BPW - H - HZMDO 10010				- 10000		2828
Fitting Position outer						
BPW - H - HZMDO 10010 D36				- 10000		2829
Fitting Position outer						
BPW - H - HZMDOM 10010				- 10000		2833
Fitting Position outer						
BPW - H - HZMDOMR 10008 D36				- 10000		2837
Fitting Position outer						
BPW - H - HZMDOMR 10010				- 10000		2838
Fitting Position outer						
BPW - H - HZMDOMU 10010				- 10000		2840
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HZMDOR 10008				- 10000		2841
Fitting Position outer						
BPW - H - HZMDOR 10010				- 10000		2842
Fitting Position outer						
BPW - H - HZMDOR 10010 D36				- 10000		2843
Fitting Position outer						
BPW - H - HZMDORU 10010				- 10000		2845
Fitting Position outer						
BPW - H - HZMDSS 2/10010				- 10000		2848
Fitting Position outer						
BPW - H - HZMDVOU 10010				- 10000		2852
Fitting Position outer						
BPW - H - HZMDVOU 10010 A				- 10000		2853
Fitting Position outer						
BPW - H - HZMH 10010				- 10000		2856
Fitting Position outer						
BPW - H - HZMH 10010-16				- 10000		2857
Fitting Position outer						
BPW - H - HZMH 11010				- 11000		2858
Fitting Position outer						
BPW - H - HZMH 11010 ECO				- 11000		2859
Fitting Position outer						
BPW - H - HZMH 11010 ECO-MAXX				- 11000		2860
Fitting Position outer						
BPW - H - HZMH 12010				- 12000		2861
Fitting Position outer						
BPW - H - HZMH 12010-16				- 12000		2862
Fitting Position outer						
BPW - H - HZMH 12010-16 ECO				- 12000		2863
Fitting Position outer						
BPW - H - HZMHO 12010 D36				- 12000		2873
Fitting Position outer						
BPW - H - HZMHOM 10010				- 10000		2874
Fitting Position outer						
BPW - H - HZMHOT 10010 D36				- 10000		2875
Fitting Position outer						
BPW - H - HZMHOT 10010-1 E36				- 10000		2876
Fitting Position outer						
BPW - H - HZMHOTA 10010				- 10000		2880
Fitting Position outer						
BPW - H - HZMHOTA 10010-1 D36				- 10000		2881
Fitting Position outer						
BPW - H - HZMHOTR 10010				- 10000		2886
Fitting Position outer						
BPW - H - HZMHOTRU 10010				- 10000		2887
Fitting Position outer						
BPW - H - HZMLL 12010/12° ECO Plus				- 12000		2890
Fitting Position outer						
BPW - H - HZMO 10010				- 10000		2892
Fitting Position outer						
BPW - H - HZMO 10010-1 D36				- 10000		2893
Fitting Position outer						
BPW - H - HZMOA 10010				- 10000		2895
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - H - HZOMRKS 12010				- 12000		2941
Fitting Position outer						
BPW - H - HZOR 10010				- 10000		2942
Fitting Position outer						
BPW - H - HZOR 10010 7/8 IN				- 10000		2943
Fitting Position outer						
BPW - H - HZOR 12010				- 12000		2944
Fitting Position outer						
BPW - H - HZORU 10010				- 10000		2947
Fitting Position outer						
BPW - H - HZOU 10010				- 10000		2949
Fitting Position outer						
BPW - H - HZVB 10010 K				- 10000		2951
Fitting Position outer						
BPW - H - HZVB 10010 K SCANIA				- 10000		2952
Fitting Position outer						
BPW - H - HZVB 10010-1 7/8 IN				- 10000		2953
Fitting Position outer						
BPW - H - HZVB 11010 K				- 11000		2954
Fitting Position outer						
BPW - H - HZVB 12010 B				- 12000		2955
Fitting Position outer						
BPW - H - HZVB 12010 K				- 12000		2956
Fitting Position outer						
BPW - H - HZVBU 10010 K				- 10000		2961
Fitting Position outer						
BPW - H - HZW 2/10010				- 10000		2963
Fitting Position outer						
BPW - H - HZW 2/11010				- 11000		2964
Fitting Position outer						
BPW - H - HZW 2/12010				- 12000		2965
Fitting Position outer						
BPW - H - HXZH 11000				- 11000		3757
Fitting Position outer						
BPW - H - HXZ 12000				- 12000		3758
Fitting Position outer						
BPW - H - HSFHLL 10010/12° ECO Plus				- 10000		3896
Fitting Position outer						
BPW - H - HSFHLL 10010/8° ECO Plus				- 10000		3905
Fitting Position outer						
BPW - H - HSFL 10010/12° ECO Plus				- 10000		3906
Fitting Position outer						
BPW - H - HSFL 12010/20° ECO Plus				- 12000		3907
Fitting Position outer						
BPW - H - HSM 12010/12° ECO Plus				- 12000		3908
Fitting Position outer						
BPW - H - HZ 12800/ 11008-16 Japan				- 12000		3909
Fitting Position outer						
BPW - H - HZF 12010/11010-16				- 12000		3910
Fitting Position outer						
BPW - H - HZF 12010-17				- 12000		3911
Fitting Position outer						
BPW - H - HXZ 11000				- 11000		4059
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KH - KH 10008				- 10000		1
Fitting Position outer						
BPW - KH - KH 10010				- 10000		2
Fitting Position outer						
BPW - KH - KH 10010/3				- 10000		3
Fitting Position outer						
BPW - KH - KHS 10010/3 ECO Plus				- 10000		9
Fitting Position outer						
BPW - KH - KHS 9010/3 ECO Plus				- 9000		12
Fitting Position outer						
BPW - KH - KHSF 10008-15				- 10000		14
Fitting Position outer						
BPW - KH - KHSF 10008-15 ECO-MAXX				- 10000		15
Fitting Position outer						
BPW - KH - KHSF 10010-15				- 10000		16
Fitting Position outer						
BPW - KH - KHSF 10010-15/3				- 10000		17
Fitting Position outer						
BPW - KH - KHSF 11008-15				- 11000		18
Fitting Position outer						
BPW - KH - KHSF 11008-15 ECO				- 11000		19
Fitting Position outer						
BPW - KH - KHSF 11008-15 ECO Plus				- 11000		20
Fitting Position outer						
BPW - KH - KHSF 11008-15 ECO-MAXX				- 11000		21
Fitting Position outer						
BPW - KH - KHSF 11010-15 ECO				- 11000		22
Fitting Position outer						
BPW - KH - KHSF 11010-15/3 ECO				- 11000		23
Fitting Position outer						
BPW - KH - KHSF 11010-15/3 ECO-MAXX				- 11000		24
Fitting Position outer						
BPW - KH - KHSF 12008-15 ECO				- 12000		25
Fitting Position outer						
BPW - KH - KHSF 12008-15 ECO Plus				- 12000		26
Fitting Position outer						
BPW - KH - KHSF 12008-15 ECO-MAXX				- 12000		27
Fitting Position outer						
BPW - KH - KHSF 12010-15 ECO				- 12000		28
Fitting Position outer						
BPW - KH - KHSF 12010-15 ECO Plus				- 12000		29
Fitting Position outer						
BPW - KH - KHSF 12010-15/3 ECO				- 12000		30
Fitting Position outer						
BPW - KH - KHSF 9010 ECO Plus				- 9000		41
Fitting Position outer						
BPW - KH - KHSFH 11008-15 ECO				- 11000		53
Fitting Position outer						
BPW - KH - KHSFH 11008-15 ECO-MAXX				- 11000		54
Fitting Position outer						
BPW - KH - KHSFH 12008-15 ECO				- 12000		55
Fitting Position outer						
BPW - KH - KHSFH 12008-15 ECO-MAXX				- 12000		56
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KH - KHSFOT 10008 D36-1				- 10000		86
Fitting Position outer						
BPW - KH - KHSM 10010-15				- 10000		90
Fitting Position outer						
BPW - KH - KHSM 11008-15 ECO				- 11000		91
Fitting Position outer						
BPW - KH - KHZF 10008-15				- 10000		118
Fitting Position outer						
BPW - KH - KHZF 10008-15 ECO				- 10000		119
Fitting Position outer						
BPW - KH - KHZF 10008-15 ECO Plus				- 10000		120
Fitting Position outer						
BPW - KH - KHZF 10008-15 ECO-MAXX				- 10000		121
Fitting Position outer						
BPW - KH - KHZF 10010-15				- 10000		122
Fitting Position outer						
BPW - KH - KHZF 10010-15 ECO				- 10000		123
Fitting Position outer						
BPW - KH - KHZF 10010-15 ECO Plus				- 10000		124
Fitting Position outer						
BPW - KH - KHZF 10010-15 ECO-MAXX				- 10000		125
Fitting Position outer						
BPW - KH - KHZF 11008-15				- 11000		126
Fitting Position outer						
BPW - KH - KHZF 11008-15 ECO				- 11000		127
Fitting Position outer						
BPW - KH - KHZF 11008-15 ECO Plus				- 11000		128
Fitting Position outer						
BPW - KH - KHZF 11008-15 ECO-MAXX				- 11000		129
Fitting Position outer						
BPW - KH - KHZF 11010-15				- 11000		130
Fitting Position outer						
BPW - KH - KHZF 11010-15 ECO				- 11000		131
Fitting Position outer						
BPW - KH - KHZF 11010-15 ECO Plus				- 11000		132
Fitting Position outer						
BPW - KH - KHZF 11010-15 ECO-MAXX				- 11000		133
Fitting Position outer						
BPW - KH - KHZF 11010-15/3 ECO				- 11000		134
Fitting Position outer						
BPW - KH - KHZF 12008-15				- 12000		135
Fitting Position outer						
BPW - KH - KHZF 12008-15 ECO				- 12000		136
Fitting Position outer						
BPW - KH - KHZF 12008-15 ECO Plus				- 12000		137
Fitting Position outer						
BPW - KH - KHZF 12008-15 ECO-MAXX				- 12000		138
Fitting Position outer						
BPW - KH - KHZF 12010-15				- 12000		139
Fitting Position outer						
BPW - KH - KHZF 12010-15 ECO				- 12000		140
Fitting Position outer						
BPW - KH - KHZF 12010-15 ECO Plus				- 12000		141
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KH - KHZF 12010-15 ECO-MAXX				- 12000		142
Fitting Position outer						
BPW - KH - KHZFB 10010-15				- 10000		157
Fitting Position outer						
BPW - KH - KHZFD 10008-15				- 10000		159
Fitting Position outer						
BPW - KH - KHZFD 10008-15 ECO				- 10000		160
Fitting Position outer						
BPW - KH - KHZFD 10010-15				- 10000		161
Fitting Position outer						
BPW - KH - KHZFD 11008-15				- 11000		162
Fitting Position outer						
BPW - KH - KHZFDH 10010-1				- 10000		170
Fitting Position outer						
BPW - KH - KHZFDH 10010-15				- 10000		171
Fitting Position outer						
BPW - KH - KHZFDHOMN 10010 D36				- 10000		177
Fitting Position outer						
BPW - KH - KHZFDO 10010 D36				- 10000		179
Fitting Position outer						
BPW - KH - KHZFDOM 10008 D36				- 10000		180
Fitting Position outer						
BPW - KH - KHZFDOM 10008 E36				- 10000		181
Fitting Position outer						
BPW - KH - KHZFDOMN 10008 E36				- 10000		182
Fitting Position outer						
BPW - KH - KHZFDOMN 10010 D36				- 10000		183
Fitting Position outer						
BPW - KH - KHZFDOMR 10010 D36				- 10000		184
Fitting Position outer						
BPW - KH - KHZFDOR 10010 D36				- 10000		185
Fitting Position outer						
BPW - KH - KHZFDOT 10008 D30				- 10000		186
Fitting Position outer						
BPW - KH - KHZFDOT 10008 D36				- 10000		187
Fitting Position outer						
BPW - KH - KHZFDOT 10008 D36-1				- 10000		188
Fitting Position outer						
BPW - KH - KHZFDOT 10010				- 10000		189
Fitting Position outer						
BPW - KH - KHZFDOT 10010 D36				- 10000		190
Fitting Position outer						
BPW - KH - KHZFDOT 10010 D36-1				- 10000		191
Fitting Position outer						
BPW - KH - KHZFDOT 10010 E36				- 10000		192
Fitting Position outer						
BPW - KH - KHZFDOT 11008 Y36-1				- 11000		193
Fitting Position outer						
BPW - KH - KHZFDOTR 10010 D36				- 10000		194
Fitting Position outer						
BPW - KH - KHZFDOTU 10010 D36				- 10000		195
Fitting Position outer						
BPW - KH - KHZFDVB 10008				- 10000		196
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KH - KHZM 11008-15 ECO				- 11000		235
Fitting Position outer						
BPW - KH - KHZM 11008-15 ECO-MAXX				- 11000		236
Fitting Position outer						
BPW - KH - KHZM 11010-15				- 11000		237
Fitting Position outer						
BPW - KH - KHZM 11010-15 ECO				- 11000		238
Fitting Position outer						
BPW - KH - KHZM 12008-15				- 12000		239
Fitting Position outer						
BPW - KH - KHZM 12008-15 ECO				- 12000		240
Fitting Position outer						
BPW - KH - KHZM 12008-15 ECO Plus				- 12000		241
Fitting Position outer						
BPW - KH - KHZM 12008-15 ECO-MAXX				- 12000		242
Fitting Position outer						
BPW - KH - KHZM 12010-15 ECO				- 12000		243
Fitting Position outer						
BPW - KH - KHZMD 10008-15				- 10000		257
Fitting Position outer						
BPW - KH - KHZMD 10008-15 ECO				- 10000		258
Fitting Position outer						
BPW - KH - KHZMD 10010-15				- 10000		259
Fitting Position outer						
BPW - KH - KHZMDH 10008-15				- 10000		265
Fitting Position outer						
BPW - KH - KHZMDOT 10008 D36				- 10000		268
Fitting Position outer						
BPW - KH - KHZMH 10008-15 ECO-MAXX				- 10000		269
Fitting Position outer						
BPW - KH - KHZMH 11008-15 ECO				- 11000		270
Fitting Position outer						
BPW - KH - KHZMH 11008-15 ECO-MAXX				- 11000		271
Fitting Position outer						
BPW - KH - KHZMH 12010-15				- 12000		272
Fitting Position outer						
BPW - KH - KHZMVB 12008				- 12000		274
Fitting Position outer						
BPW - KH - KHZMVB 12008 KN				- 12000		275
Fitting Position outer						
BPW - KH - KHSF 9008/3 ECO-MAXX				- 12000		3919
Fitting Position outer						
BPW - KH - KHZFD 1008-15				- 10000		3921
Fitting Position outer						
BPW - KH - KHZFD 12010-15				- 12000		3922
Fitting Position outer						
BPW - KH - KHSF 10008-15 ECO Plus				- 10000		4060
Fitting Position outer						
BPW - KH - KHSF 11010-15 ECO Plus				- 11000		4061
Fitting Position outer						
BPW - KH - KHSFH 11008-15 ECO Plus				- 11000		4062
Fitting Position outer						
BPW - KH - KHSM 10008-15 ECO Plus				- 11000		4063
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KH - KHZFH 11010-15 ECO Plus				- 11000		4064
Fitting Position outer						
BPW - KH - KHZM 11008-15 ECO Plus				- 11000		4065
Fitting Position outer						
BPW - KM - KMSFL 12008/34/34° ECO-MAXX				- 12000		282
Fitting Position outer						
BPW - KM - KMSFL 12008/34° ECO-MAXX				- 12000		283
Fitting Position outer						
BPW - KM - KMSFLL 12008 ECO-MAXX				- 12000		293
Fitting Position outer						
BPW - KM - KMSFLL 12008/12° ECO-MAXX				- 12000		294
Fitting Position outer						
BPW - KM - KMSFLL 12008/20° ECO-MAXX				- 12000		295
Fitting Position outer						
BPW - KM - KMZF 12008 ECO-MAXX				- 12000		304
Fitting Position outer						
BPW - KM - KMZF 12010 ECO-MAXX				- 12000		305
Fitting Position outer						
BPW - KM - KMZFH 12010 ECO-MAXX				- 12000		311
Fitting Position outer						
BPW - KM - KMZFL 12008/34/34° ECO-MAXX				- 12000		312
Fitting Position outer						
BPW - KM - KMZFL 12008/34° ECO-MAXX				- 12000		313
Fitting Position outer						
BPW - KM - KMZFL 12008/45/45° ECO-MAXX				- 12000		314
Fitting Position outer						
BPW - KM - KMZFL 12010/34/34° ECO-MAXX				- 12000		315
Fitting Position outer						
BPW - KM - KMZFL 12010/34° ECO-MAXX				- 12000		316
Fitting Position outer						
BPW - KM - KMZFL 12010/38/36° ECO-MAXX				- 12000		317
Fitting Position outer						
BPW - KM - KMZFL 12010/38/38° ECO-MAXX				- 12000		318
Fitting Position outer						
BPW - KM - KMZFL 12010/38° ECO-MAXX				- 12000		319
Fitting Position outer						
BPW - KM - KMZFL 12010/45/45° ECO-MAXX				- 12000		320
Fitting Position outer						
BPW - KM - KMZFL 12010/45° ECO-MAXX				- 12000		321
Fitting Position outer						
BPW - KM - KMZFLL 10008/18°				- 10000		323
Fitting Position outer						
BPW - KM - KMZFLL 10008/23°				- 10000		324
Fitting Position outer						
BPW - KM - KMZFLL 12008 ECO-MAXX				- 12000		325
Fitting Position outer						
BPW - KM - KMZFLL 12008/15° ECO Plus				- 12000		326
Fitting Position outer						
BPW - KM - KMZFLL 12008/15° ECO-MAXX				- 12000		327
Fitting Position outer						
BPW - KM - KMZFLL 12008/18° ECO-MAXX				- 12000		328
Fitting Position outer						
BPW - KM - KMZFLL 12008/20° ECO-MAXX				- 12000		329
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KM - KMZFLL 12008/23/24° ECO-MAXX				- 12000		330
Fitting Position outer						
BPW - KM - KMZFLL 12008/23/24° ECO Plus				- 12000		331
Fitting Position outer						
BPW - KM - KMZFLL 12008/27/28° ECO-MAXX				- 12000		332
Fitting Position outer						
BPW - KM - KMZFLL 12010/18° ECO Plus				- 12000		333
Fitting Position outer						
BPW - KM - KMZFLL 12010/15° ECO-MAXX				- 12000		334
Fitting Position outer						
BPW - KM - KMZFLL 12010/18° ECO-MAXX				- 12000		336
Fitting Position outer						
BPW - KM - KMZMVB 12008 K				- 12000		358
Fitting Position outer						
BPW - KM - KMSML 12008/34/34° ECO-MAXX				- 12000		3926
Fitting Position outer						
BPW - KM - KMZFHL 12008/45/45° ECO-MAXX				- 12000		3927
Fitting Position outer						
BPW - KM - KMZFLL 12008/12° ECO Plus				- 12000		3928
Fitting Position outer						
BPW - KM - KMZFLL 12008/27/28° ECO Plus				- 12000		3929
Fitting Position outer						
BPW - KM - KMZMLL 12008/18° ECO Plus				- 12000		3930
Fitting Position outer						
BPW - KM - KMZFLL 12010/12° ECO-MAXX				- 12000		3931
Fitting Position outer						
BPW - KM - KMZFLL 12010/15° ECO Plus				- 12000		3933
Fitting Position outer						
BPW - KM - KMZML 12008/34/34° ECO-MAXX				- 12000		3934
Fitting Position outer						
BPW - KM - KMZFLL 12008/18° ECO Plus				- 12000		3936
Fitting Position outer						
BPW - KR - KR 10008				- 10000		359
Fitting Position outer						
BPW - KR - KR 10010				- 10000		360
Fitting Position outer						
BPW - KR - KR 12010				- 12000		361
Fitting Position outer						
BPW - KR - KRBM 10010 L				- 10000		367
Fitting Position outer						
BPW - KR - KRDZM 10008				- 10000		373
Fitting Position outer						
BPW - KR - KRSF 10008-20				- 10000		377
Fitting Position outer						
BPW - KR - KRSF 12008				- 12000		378
Fitting Position outer						
BPW - KR - KRSF 12008 ECO				- 12000		379
Fitting Position outer						
BPW - KR - KRSF 12008 ECO-MAXX				- 12000		380
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KR - KRSF 12008-20				- 12000		381
Fitting Position outer						
BPW - KR - KRSF 12008-20 ECO				- 12000		382
Fitting Position outer						
BPW - KR - KRSF 12008-20 ECO-MAXX				- 12000		383
Fitting Position outer						
BPW - KR - KRSM 10008-17				- 10000		386
Fitting Position outer						
BPW - KR - KRSM 10010-17				- 10000		387
Fitting Position outer						
BPW - KR - KRZ 10010-30				- 10000		392
Fitting Position outer						
BPW - KR - KRZ 12010				- 12000		393
Fitting Position outer						
BPW - KR - KRZ 12010-30				- 12000		394
Fitting Position outer						
BPW - KR - KRZD 10008				- 10000		395
Fitting Position outer						
BPW - KR - KRZD 10008-17				- 10000		396
Fitting Position outer						
BPW - KR - KRZD 10008-20				- 10000		397
Fitting Position outer						
BPW - KR - KRZD 10010				- 10000		398
Fitting Position outer						
BPW - KR - KRZD 10010-17				- 10000		399
Fitting Position outer						
BPW - KR - KRZD 10010-20				- 10000		400
Fitting Position outer						
BPW - KR - KRZDH 10010-20				- 10000		407
Fitting Position outer						
BPW - KR - KRZDHOT 10010				- 10000		409
Fitting Position outer						
BPW - KR - KRZDO 10008 D36				- 10000		410
Fitting Position outer						
BPW - KR - KRZDO 10010 D36				- 10000		411
Fitting Position outer						
BPW - KR - KRZDOM 10010 D36				- 10000		412
Fitting Position outer						
BPW - KR - KRZDOMN 10008 D36				- 10000		413
Fitting Position outer						
BPW - KR - KRZDOMN 10010 D36				- 10000		414
Fitting Position outer						
BPW - KR - KRZDOMR 10010 D36				- 10000		415
Fitting Position outer						
BPW - KR - KRZDOT 10008 D36				- 10000		416
Fitting Position outer						
BPW - KR - KRZDOT 10010				- 10000		417
Fitting Position outer						
BPW - KR - KRZDOT 10010 D36				- 10000		418
Fitting Position outer						
BPW - KR - KRZDOT 10010 D36-1				- 10000		419
Fitting Position outer						
BPW - KR - KRZDOTR 10008 D36				- 10000		420
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KR - KRZDOTR 10010 D36				- 10000		421
Fitting Position outer						
BPW - KR - KRZF 10010-20				- 10000		422
Fitting Position outer						
BPW - KR - KRZF 12010 ECO				- 12000		423
Fitting Position outer						
BPW - KR - KRZF 12010-20 ECO				- 12000		424
Fitting Position outer						
BPW - KR - KRZFD 10008-20				- 10000		426
Fitting Position outer						
BPW - KR - KRZFD 10010-17				- 10000		427
Fitting Position outer						
BPW - KR - KRZFD 10010-20				- 10000		428
Fitting Position outer						
BPW - KR - KRZFDH 10010-20				- 10000		431
Fitting Position outer						
BPW - KR - KRZFDOMN 10008 D36				- 10000		433
Fitting Position outer						
BPW - KR - KRZFDOMN 10008 E36				- 10000		434
Fitting Position outer						
BPW - KR - KRZFDOT 10008 D36				- 10000		435
Fitting Position outer						
BPW - KR - KRZFDOT 10008 D36-1				- 10000		436
Fitting Position outer						
BPW - KR - KRZFDOT 10010 D36				- 10000		437
Fitting Position outer						
BPW - KR - KRZM 11010-17				- 11000		441
Fitting Position outer						
BPW - KR - KRZM 11010-30				- 11000		442
Fitting Position outer						
BPW - KR - KRZM 12008-20				- 12000		443
Fitting Position outer						
BPW - KR - KRZM 12008-30				- 12000		444
Fitting Position outer						
BPW - KR - KRZM 12010-20				- 12000		445
Fitting Position outer						
BPW - KR - KRZM 12010-30				- 12000		446
Fitting Position outer						
BPW - KR - KRZMD 10008				- 10000		450
Fitting Position outer						
BPW - KR - KRZMD 10008-17				- 10000		451
Fitting Position outer						
BPW - KR - KRZMD 10008-20				- 10000		452
Fitting Position outer						
BPW - KR - KRZMD 10010				- 10000		453
Fitting Position outer						
BPW - KR - KRZMD 10010-17				- 10000		454
Fitting Position outer						
BPW - KR - KRZMD 10010-20				- 10000		455
Fitting Position outer						
BPW - KR - KRZMDH 10008-20				- 10000		463
Fitting Position outer						
BPW - KR - KRZMDH 10010-17				- 10000		464
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KR - KRZMDH 10010-20				- 10000		465
Fitting Position outer						
BPW - KR - KRZMDHOT 10008 D36				- 10000		468
Fitting Position outer						
BPW - KR - KRZMDHOT 10010 D36				- 10000		469
Fitting Position outer						
BPW - KR - KRZMDHOTU 10008 D36				- 10000		471
Fitting Position outer						
BPW - KR - KRZMDO 10008 E36				- 10000		472
Fitting Position outer						
BPW - KR - KRZMDOM 10008				- 10000		473
Fitting Position outer						
BPW - KR - KRZMDOM 10008 D36				- 10000		474
Fitting Position outer						
BPW - KR - KRZMDOM 10008 D36-1				- 10000		475
Fitting Position outer						
BPW - KR - KRZMDOM 10008 E36				- 10000		476
Fitting Position outer						
BPW - KR - KRZMDOM 10010				- 10000		477
Fitting Position outer						
BPW - KR - KRZMDOM 10010 D36-1				- 10000		478
Fitting Position outer						
BPW - KR - KRZMDOMN 10008 D36				- 10000		479
Fitting Position outer						
BPW - KR - KRZMDOMN 10008 E36				- 10000		480
Fitting Position outer						
BPW - KR - KRZMDOMNU 10008 D36				- 10000		481
Fitting Position outer						
BPW - KR - KRZMDOMR 10008				- 10000		482
Fitting Position outer						
BPW - KR - KRZMDOMR 10008 D36				- 10000		483
Fitting Position outer						
BPW - KR - KRZMDOMR 10010 D36				- 10000		484
Fitting Position outer						
BPW - KR - KRZMDOMU 10008 D36				- 10000		485
Fitting Position outer						
BPW - KR - KRZMDOR 10008 D36				- 10000		486
Fitting Position outer						
BPW - KR - KRZMDOT 10008				- 10000		487
Fitting Position outer						
BPW - KR - KRZMDOT 10008 D36				- 10000		488
Fitting Position outer						
BPW - KR - KRZMDOT 10008 D36-1				- 10000		489
Fitting Position outer						
BPW - KR - KRZMDOT 10008 E36				- 10000		490
Fitting Position outer						
BPW - KR - KRZMDOT 10010				- 10000		491
Fitting Position outer						
BPW - KR - KRZMDOT 10010 D36				- 10000		492
Fitting Position outer						
BPW - KR - KRZMDOT 10010 E36				- 10000		493
Fitting Position outer						
BPW - KR - KRZMDOTR 10008 D36				- 10000		494
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - KR - KRZMDOTR 10010 D36				- 10000		495
Fitting Position outer						
BPW - KR - KRZMDOTU 10008				- 10000		496
Fitting Position outer						
BPW - KR - KRZMDOTU 10008 D36				- 10000		497
Fitting Position outer						
BPW - KR - KRZMDOTU 10010 D36				- 10000		498
Fitting Position outer						
BPW - KR - KRZMDVBT 10008				- 10000		501
Fitting Position outer						
BPW - KR - KRZMDVBT 10008 K				- 10000		502
Fitting Position outer						
BPW - KR - KRZMDVBT 10010				- 10000		503
Fitting Position outer						
BPW - KR - KRZMDVBT 10010 M				- 10000		504
Fitting Position outer						
BPW - KR - KRZMDVBTU 10008 K				- 10000		505
Fitting Position outer						
BPW - KR - KRZMH 12010-20				- 12000		506
Fitting Position outer						
BPW - KR - KRZMOT 11010 D36				- 11000		507
Fitting Position outer						
BPW - KR - KRZOM 10010 D36				- 10000		508
Fitting Position outer						
BPW - KR - KRZOM 12010 D36				- 12000		509
Fitting Position outer						
BPW - KR - KRZOT 12010 D36				- 12000		510
Fitting Position outer						
BPW - KR - KRZF 12010-30				- 12000		3750
Fitting Position outer						
BPW - M - MZFLL 9010/12° ECO Plus				- 9000		524
Fitting Position outer						
BPW - NH - NHL 12010 R				- 12000		646
Fitting Position outer						
BPW - NH - NHSF 12010-15 ECO				- 12000		652
Fitting Position outer						
BPW - NH - NHSF 12010-15 ECO-MAXX				- 12000		653
Fitting Position outer						
BPW - NH - NHXZ 11000-15				- 11000		669
Fitting Position outer						
BPW - NH - NHXZ 11010-15				- 11000		670
Fitting Position outer						
BPW - NH - NHZF 10010-15				- 10000		679
Fitting Position outer						
BPW - NH - NHZF 10010-15 ECO				- 10000		680
Fitting Position outer						
BPW - NH - NHZF 10010-15 ECO-MAXX				- 10000		681
Fitting Position outer						
BPW - NH - NHZF 11010-15				- 11000		682
Fitting Position outer						
BPW - NH - NHZF 11010-15 ECO				- 11000		683
Fitting Position outer						
BPW - NH - NHZF 11010-15 ECO-MAXX				- 11000		684
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NH - NHZF 12010-15 ECO				- 12000		685
Fitting Position outer						
BPW - NH - NHZF 12010-15 ECO-MAXX				- 12000		686
Fitting Position outer						
BPW - NH - NHZF 12010-15EG ECO				- 12000		687
Fitting Position outer						
BPW - NH - NHZF 12010-15EG ECO-MAXX				- 12000		688
Fitting Position outer						
BPW - NH - NHZFH 10010-15				- 10000		706
Fitting Position outer						
BPW - NH - NHZFH 10010-15 ECO				- 10000		707
Fitting Position outer						
BPW - NH - NHZFH 10010-15 ECO-MAXX				- 10000		708
Fitting Position outer						
BPW - NH - NHZFH 11010-15				- 11000		709
Fitting Position outer						
BPW - NH - NHZFH 11010-15 ECO				- 11000		710
Fitting Position outer						
BPW - NH - NHZFH 11010-15 ECO-MAXX				- 11000		711
Fitting Position outer						
BPW - NH - NHZFH 12010-15 ECO				- 12000		712
Fitting Position outer						
BPW - NH - NHZFH 12010-15 ECO-MAXX				- 12000		713
Fitting Position outer						
BPW - NH - NHZFVB 10010 KN ECO				- 10000		727
Fitting Position outer						
BPW - NH - NHZM 10010-15				- 10000		730
Fitting Position outer						
BPW - NH - NHZM 10010-15 ECO				- 10000		731
Fitting Position outer						
BPW - NH - NHZM 10010-15 ECO-MAXX				- 10000		732
Fitting Position outer						
BPW - NH - NHZM 11010-15				- 11000		733
Fitting Position outer						
BPW - NH - NHZM 11010-15 ECO				- 11000		734
Fitting Position outer						
BPW - NH - NHZM 11010-15 ECO-MAXX				- 11000		735
Fitting Position outer						
BPW - NH - NHZM 12010-15 ECO				- 12000		736
Fitting Position outer						
BPW - NH - NHZM 12010-15 ECO-MAXX				- 12000		737
Fitting Position outer						
BPW - NH - NHZMH 11010-15 ECO-MAXX				- 11000		756
Fitting Position outer						
BPW - NH - NHZMH 12010-15 ECO-MAXX				- 12000		757
Fitting Position outer						
BPW - NR - NRDZF 13010				- 11000		778
Fitting Position outer						
BPW - NR - NRIZ 10000				- 10000		783
Fitting Position outer						
BPW - NR - NRIZ 11000-20				- 11000		784
Fitting Position outer						
BPW - NR - NRIZ 12000				- 12000		785
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRIZD 10000				- 10000		791
Fitting Position outer						
BPW - NR - NRIZDH 10000				- 10000		795
Fitting Position outer						
BPW - NR - NRIZH 10000-17				- 10000		798
Fitting Position outer						
BPW - NR - NRIZOT 10000				- 10000		800
Fitting Position outer						
BPW - NR - NRS 11010				- 11000		808
Fitting Position outer						
BPW - NR - NRSF 12010-20				- 12000		820
Fitting Position outer						
BPW - NR - NRSM 10010-17				- 10000		840
Fitting Position outer						
BPW - NR - NR 10010				- 10000		942
Fitting Position outer						
BPW - NR - NR 11010				- 11000		943
Fitting Position outer						
BPW - NR - NR 12010				- 12000		944
Fitting Position outer						
BPW - NR - NRXZ 10000				- 10000		978
Fitting Position outer						
BPW - NR - NRXZ 10000-17				- 10000		979
Fitting Position outer						
BPW - NR - NRXZ 10000-20				- 10000		980
Fitting Position outer						
BPW - NR - NRXZ 10010				- 10000		981
Fitting Position outer						
BPW - NR - NRXZ 10010-17				- 10000		982
Fitting Position outer						
BPW - NR - NRXZ 10010-20				- 10000		983
Fitting Position outer						
BPW - NR - NRXZ 10010-30				- 10000		984
Fitting Position outer						
BPW - NR - NRXZ 11000-20				- 11000		985
Fitting Position outer						
BPW - NR - NRXZ 11000-30				- 11000		986
Fitting Position outer						
BPW - NR - NRXZ 11010-20				- 11000		987
Fitting Position outer						
BPW - NR - NRXZ 11010-30				- 11000		988
Fitting Position outer						
BPW - NR - NRXZ 12000				- 12000		989
Fitting Position outer						
BPW - NR - NRXZ 12000-20				- 12000		990
Fitting Position outer						
BPW - NR - NRXZ 12000-30				- 12000		991
Fitting Position outer						
BPW - NR - NRXZ 12010-20				- 12000		992
Fitting Position outer						
BPW - NR - NRXZ 12010-30				- 12000		993
Fitting Position outer						
BPW - NR - NRXZH 11000				- 11000		1005
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRXZH 11010				- 11000		1006
Fitting Position outer						
BPW - NR - NRXZOTR 10000				- 10000		1007
Fitting Position outer						
BPW - NR - NRXZOTR 10000 D36				- 10000		1008
Fitting Position outer						
BPW - NR - NRXZOTR 10010				- 10000		1009
Fitting Position outer						
BPW - NR - NRXZOTR 10010 D36				- 10000		1010
Fitting Position outer						
BPW - NR - NRXZVB 10000 K				- 10000		1011
Fitting Position outer						
BPW - NR - NRXZVB 10010 K				- 10000		1012
Fitting Position outer						
BPW - NR - NRXZVBT 10000 K				- 10000		1013
Fitting Position outer						
BPW - NR - NRXZVBT 10010 K				- 10000		1014
Fitting Position outer						
BPW - NR - NRXZVBU 10000 K				- 10000		1015
Fitting Position outer						
BPW - NR - NRXZVBU 10010 K				- 10000		1016
Fitting Position outer						
BPW - NR - NRZ 10010				- 10000		1017
Fitting Position outer						
BPW - NR - NRZ 10010-17				- 10000		1018
Fitting Position outer						
BPW - NR - NRZ 10010-20				- 10000		1019
Fitting Position outer						
BPW - NR - NRZ 10010-30				- 10000		1020
Fitting Position outer						
BPW - NR - NRZ 11010				- 11000		1021
Fitting Position outer						
BPW - NR - NRZ 11010-17				- 11000		1022
Fitting Position outer						
BPW - NR - NRZ 11010-20				- 11000		1023
Fitting Position outer						
BPW - NR - NRZ 12010				- 12000		1024
Fitting Position outer						
BPW - NR - NRZ 12010-20				- 12000		1025
Fitting Position outer						
BPW - NR - NRZ 12010-30				- 12000		1026
Fitting Position outer						
BPW - NR - NRZA 10010-30				- 10000		1048
Fitting Position outer						
BPW - NR - NRZD 10010				- 10000		1049
Fitting Position outer						
BPW - NR - NRZD 10010-17				- 10000		1050
Fitting Position outer						
BPW - NR - NRZD 10010-20				- 10000		1051
Fitting Position outer						
BPW - NR - NRZDH 10010				- 10000		1065
Fitting Position outer						
BPW - NR - NRZDH 10010-17				- 10000		1066
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZDH 10010-20				- 10000		1067
Fitting Position outer						
BPW - NR - NRZDHOM 10010				- 10000		1074
Fitting Position outer						
BPW - NR - NRZDHOT 10010				- 10000		1075
Fitting Position outer						
BPW - NR - NRZDHOT 10010 D36				- 10000		1076
Fitting Position outer						
BPW - NR - NRZDHOTA 10010 D36				- 10000		1087
Fitting Position outer						
BPW - NR - NRZDHOTR 10010 D36				- 10000		1088
Fitting Position outer						
BPW - NR - NRZDO 10010				- 10000		1094
Fitting Position outer						
BPW - NR - NRZDO 10010 D36				- 10000		1095
Fitting Position outer						
BPW - NR - NRZDOM 10010				- 10000		1100
Fitting Position outer						
BPW - NR - NRZDOMN 10010 D36				- 10000		1106
Fitting Position outer						
BPW - NR - NRZDOMR 10010				- 10000		1110
Fitting Position outer						
BPW - NR - NRZDOMR 10010 D36				- 10000		1111
Fitting Position outer						
BPW - NR - NRZDOR 10010				- 10000		1119
Fitting Position outer						
BPW - NR - NRZDOT 10010				- 10000		1122
Fitting Position outer						
BPW - NR - NRZDOT 10010 D36				- 10000		1123
Fitting Position outer						
BPW - NR - NRZDOT 10010 D36-1				- 10000		1124
Fitting Position outer						
BPW - NR - NRZDOTA 10010 D36				- 10000		1144
Fitting Position outer						
BPW - NR - NRZDOTR 10010				- 10000		1149
Fitting Position outer						
BPW - NR - NRZDOTR 10010 D36				- 10000		1150
Fitting Position outer						
BPW - NR - NRZDOTU 10010				- 10000		1163
Fitting Position outer						
BPW - NR - NRZDOTU 10010 D36				- 10000		1164
Fitting Position outer						
BPW - NR - NRZDSS 2/10010				- 10000		1166
Fitting Position outer						
BPW - NR - NRZDVB 10010 K				- 10000		1170
Fitting Position outer						
BPW - NR - NRZDVBT 10010				- 10000		1171
Fitting Position outer						
BPW - NR - NRZDVBT 10010 C				- 10000		1172
Fitting Position outer						
BPW - NR - NRZDVBT 10010 HK				- 10000		1173
Fitting Position outer						
BPW - NR - NRZDVBT 10010 K				- 10000		1174
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZDVBU 10010				- 10000		1180
Fitting Position outer						
BPW - NR - NRZDVBU 10010 K				- 10000		1181
Fitting Position outer						
BPW - NR - NRZF 10010				- 10000		1186
Fitting Position outer						
BPW - NR - NRZF 10010 ECO				- 10000		1187
Fitting Position outer						
BPW - NR - NRZF 10010-12				- 10000		1188
Fitting Position outer						
BPW - NR - NRZF 10010-17				- 10000		1189
Fitting Position outer						
BPW - NR - NRZF 10010-17 ECO				- 10000		1190
Fitting Position outer						
BPW - NR - NRZF 10010-20				- 10000		1191
Fitting Position outer						
BPW - NR - NRZF 10010-20 ECO				- 10000		1192
Fitting Position outer						
BPW - NR - NRZF 10010-30				- 10000		1193
Fitting Position outer						
BPW - NR - NRZF 10010-30 ECO				- 10000		1194
Fitting Position outer						
BPW - NR - NRZF 10010-42				- 10000		1195
Fitting Position outer						
BPW - NR - NRZF 11010				- 11000		1196
Fitting Position outer						
BPW - NR - NRZF 11010 ECO				- 11000		1197
Fitting Position outer						
BPW - NR - NRZF 11010-17				- 11000		1198
Fitting Position outer						
BPW - NR - NRZF 11010-17 ECO				- 11000		1199
Fitting Position outer						
BPW - NR - NRZF 11010-17 ECO-MAXX				- 11000		1200
Fitting Position outer						
BPW - NR - NRZF 11010-20				- 11000		1201
Fitting Position outer						
BPW - NR - NRZF 11010-20 ECO				- 11000		1202
Fitting Position outer						
BPW - NR - NRZF 11010-30				- 11000		1203
Fitting Position outer						
BPW - NR - NRZF 11010-30 ECO				- 11000		1204
Fitting Position outer						
BPW - NR - NRZF 12010				- 12000		1205
Fitting Position outer						
BPW - NR - NRZF 12010 ECO				- 12000		1206
Fitting Position outer						
BPW - NR - NRZF 12010 ECO-MAXX				- 12000		1207
Fitting Position outer						
BPW - NR - NRZF 12010-17				- 12000		1208
Fitting Position outer						
BPW - NR - NRZF 12010-17 ECO				- 12000		1209
Fitting Position outer						
BPW - NR - NRZF 12010-20				- 12000		1210
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZF 12010-20 ECO				- 12000		1211
Fitting Position outer						
BPW - NR - NRZF 12010-20 ECO-MAXX				- 12000		1212
Fitting Position outer						
BPW - NR - NRZF 12010-30				- 12000		1213
Fitting Position outer						
BPW - NR - NRZF 12010-30 ECO				- 12000		1214
Fitting Position outer						
BPW - NR - NRZF 12010-30 ECO-MAXX				- 12000		1215
Fitting Position outer						
BPW - NR - NRZFA 10010-30				- 10000		1231
Fitting Position outer						
BPW - NR - NRZFD 10010				- 10000		1232
Fitting Position outer						
BPW - NR - NRZFD 10010-17				- 10000		1233
Fitting Position outer						
BPW - NR - NRZFD 10010-20				- 10000		1234
Fitting Position outer						
BPW - NR - NRZFDH 10010-17				- 10000		1239
Fitting Position outer						
BPW - NR - NRZFDH 10010-20				- 10000		1240
Fitting Position outer						
BPW - NR - NRZFDOT 10010 D36				- 10000		1244
Fitting Position outer						
BPW - NR - NRZFH 10010				- 10000		1247
Fitting Position outer						
BPW - NR - NRZFH 10010-17				- 10000		1248
Fitting Position outer						
BPW - NR - NRZFH 10010-17 ECO				- 10000		1249
Fitting Position outer						
BPW - NR - NRZFH 10010-17 ECO-MAXX				- 10000		1250
Fitting Position outer						
BPW - NR - NRZFH 10010-20				- 10000		1251
Fitting Position outer						
BPW - NR - NRZFH 10010-20 ECO				- 10000		1252
Fitting Position outer						
BPW - NR - NRZFH 10010-30				- 10000		1253
Fitting Position outer						
BPW - NR - NRZFH 11010-17				- 11000		1254
Fitting Position outer						
BPW - NR - NRZFH 11010-17 ECO				- 11000		1255
Fitting Position outer						
BPW - NR - NRZFH 11010-17 ECO-MAXX				- 11000		1256
Fitting Position outer						
BPW - NR - NRZFH 11010-20				- 11000		1257
Fitting Position outer						
BPW - NR - NRZFH 11010-30				- 11000		1258
Fitting Position outer						
BPW - NR - NRZFH 11010-30 ECO-MAXX				- 11000		1259
Fitting Position outer						
BPW - NR - NRZFH 12010				- 12000		1260
Fitting Position outer						
BPW - NR - NRZFH 12010-17				- 12000		1261
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZFH 12010-20				- 12000		1262
Fitting Position outer						
BPW - NR - NRZFH 12010-20 ECO				- 12000		1263
Fitting Position outer						
BPW - NR - NRZFH 12010-30				- 12000		1264
Fitting Position outer						
BPW - NR - NRZFH 12010-30 ECO				- 12000		1265
Fitting Position outer						
BPW - NR - NRZFH 12010-30 ECO-MAXX				- 12000		1266
Fitting Position outer						
BPW - NR - NRZFHOT 10010 D30				- 10000		1275
Fitting Position outer						
BPW - NR - NRZFHOT 10010 D36				- 10000		1276
Fitting Position outer						
BPW - NR - NRZFHOTU 10010 D36				- 10000		1279
Fitting Position outer						
BPW - NR - NRZFOT 10010 D36				- 10000		1281
Fitting Position outer						
BPW - NR - NRZFOT 10010 D36-1				- 10000		1282
Fitting Position outer						
BPW - NR - NRZFVB 10010 K				- 10000		1300
Fitting Position outer						
BPW - NR - NRZFVB 10010 KB				- 10000		1301
Fitting Position outer						
BPW - NR - NRZFVB 10010 KN				- 10000		1302
Fitting Position outer						
BPW - NR - NRZFBVT 10010 K				- 10000		1305
Fitting Position outer						
BPW - NR - NRZFBVT 10010 M				- 10000		1306
Fitting Position outer						
BPW - NR - NRZFBVT 12010 M				- 12000		1307
Fitting Position outer						
BPW - NR - NRZH 10010				- 10000		1313
Fitting Position outer						
BPW - NR - NRZH 10010-20				- 10000		1314
Fitting Position outer						
BPW - NR - NRZH 10010-30				- 10000		1315
Fitting Position outer						
BPW - NR - NRZH 11010				- 11000		1316
Fitting Position outer						
BPW - NR - NRZH 11010-17				- 11000		1317
Fitting Position outer						
BPW - NR - NRZH 12010				- 12000		1318
Fitting Position outer						
BPW - NR - NRZH 12010-20				- 12000		1319
Fitting Position outer						
BPW - NR - NRZH 12010-30				- 12000		1320
Fitting Position outer						
BPW - NR - NRZHOT 10010				- 10000		1326
Fitting Position outer						
BPW - NR - NRZHOTR 10010				- 10000		1327
Fitting Position outer						
BPW - NR - NRZM 10010				- 10000		1328
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZM 10010-17				- 10000		1329
Fitting Position outer						
BPW - NR - NRZM 10010-20				- 10000		1330
Fitting Position outer						
BPW - NR - NRZM 10010-30				- 10000		1331
Fitting Position outer						
BPW - NR - NRZM 10010-40				- 10000		1332
Fitting Position outer						
BPW - NR - NRZM 11010				- 11000		1333
Fitting Position outer						
BPW - NR - NRZM 11010-17				- 11000		1334
Fitting Position outer						
BPW - NR - NRZM 11010-17 ECO				- 11000		1335
Fitting Position outer						
BPW - NR - NRZM 11010-20				- 11000		1336
Fitting Position outer						
BPW - NR - NRZM 11010-30				- 11000		1337
Fitting Position outer						
BPW - NR - NRZM 12010				- 12000		1338
Fitting Position outer						
BPW - NR - NRZM 12010-17				- 12000		1339
Fitting Position outer						
BPW - NR - NRZM 12010-20				- 12000		1340
Fitting Position outer						
BPW - NR - NRZM 12010-30				- 12000		1341
Fitting Position outer						
BPW - NR - NRZMD 10010				- 10000		1360
Fitting Position outer						
BPW - NR - NRZMD 10010-17				- 10000		1361
Fitting Position outer						
BPW - NR - NRZMD 10010-20				- 10000		1362
Fitting Position outer						
BPW - NR - NRZMD 12010				- 12000		1363
Fitting Position outer						
BPW - NR - NRZMD 12010-20				- 12000		1364
Fitting Position outer						
BPW - NR - NRZMDH 10010				- 10000		1375
Fitting Position outer						
BPW - NR - NRZMDH 10010-17				- 10000		1376
Fitting Position outer						
BPW - NR - NRZMDH 10010-20				- 10000		1377
Fitting Position outer						
BPW - NR - NRZMDO 10010 D36				- 10000		1391
Fitting Position outer						
BPW - NR - NRZMDOMN 10010 D36				- 10000		1393
Fitting Position outer						
BPW - NR - NRZMDOMR 10010				- 10000		1396
Fitting Position outer						
BPW - NR - NRZMDOT 10010				- 10000		1398
Fitting Position outer						
BPW - NR - NRZMDOT 10010 D36				- 10000		1399
Fitting Position outer						
BPW - NR - NRZMDOTR 10010				- 10000		1407
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZMDOTR 10010 D36				- 10000		1408
Fitting Position outer						
BPW - NR - NRZMDVBT 10010				- 10000		1416
Fitting Position outer						
BPW - NR - NRZMDVBT 10010 K				- 10000		1417
Fitting Position outer						
BPW - NR - NRZMH 10010				- 10000		1420
Fitting Position outer						
BPW - NR - NRZMH 10010-20				- 10000		1421
Fitting Position outer						
BPW - NR - NRZMH 11010-17				- 11000		1422
Fitting Position outer						
BPW - NR - NRZMH 12010-20				- 12000		1423
Fitting Position outer						
BPW - NR - NRZMH 12010-30				- 12000		1424
Fitting Position outer						
BPW - NR - NRZMHOT 10010				- 10000		1431
Fitting Position outer						
BPW - NR - NRZMHOT 10010 D36				- 10000		1432
Fitting Position outer						
BPW - NR - NRZMHR 10010				- 10000		1435
Fitting Position outer						
BPW - NR - NRZMOMR 10010				- 10000		1436
Fitting Position outer						
BPW - NR - NRZMOMR 10010 D36				- 10000		1437
Fitting Position outer						
BPW - NR - NRZMOT 10010				- 10000		1438
Fitting Position outer						
BPW - NR - NRZMOT 10010 D36				- 10000		1439
Fitting Position outer						
BPW - NR - NRZMOTR 10010				- 10000		1444
Fitting Position outer						
BPW - NR - NRZMOTR 10010 D36				- 10000		1445
Fitting Position outer						
BPW - NR - NRZMOTRU 10010				- 10000		1446
Fitting Position outer						
BPW - NR - NRZMSS 2/10010				- 10000		1447
Fitting Position outer						
BPW - NR - NRZMVB 10010 K				- 10000		1448
Fitting Position outer						
BPW - NR - NRZMVB 10010 M				- 10000		1449
Fitting Position outer						
BPW - NR - NRZO 10010				- 10000		1452
Fitting Position outer						
BPW - NR - NRZO 10010 D36				- 10000		1453
Fitting Position outer						
BPW - NR - NRZOM 10010				- 10000		1455
Fitting Position outer						
BPW - NR - NRZOMN 10010 D36				- 10000		1456
Fitting Position outer						
BPW - NR - NRZOMNU 10010 D36				- 10000		1457
Fitting Position outer						
BPW - NR - NRZOMR 10010				- 10000		1458
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - NR - NRZOMU 10010				- 10000		1462
Fitting Position outer						
BPW - NR - NRZOR 10010				- 10000		1463
Fitting Position outer						
BPW - NR - NRZOT 10010				- 10000		1464
Fitting Position outer						
BPW - NR - NRZOT 10010 D36				- 10000		1465
Fitting Position outer						
BPW - NR - NRZOT 10010 D36-1				- 10000		1466
Fitting Position outer						
BPW - NR - NRZOT 10010 E36				- 10000		1467
Fitting Position outer						
BPW - NR - NRZOTR 10010				- 10000		1475
Fitting Position outer						
BPW - NR - NRZOTRU 10010				- 10000		1478
Fitting Position outer						
BPW - NR - NRZOTU 10010				- 10000		1479
Fitting Position outer						
BPW - NR - NRZOTU 10010 D36				- 10000		1480
Fitting Position outer						
BPW - NR - NRZOU 10010				- 10000		1481
Fitting Position outer						
BPW - NR - NRZVB 10010				- 10000		1482
Fitting Position outer						
BPW - NR - NRZVB 10010 C				- 10000		1483
Fitting Position outer						
BPW - NR - NRZVB 10010 K				- 10000		1484
Fitting Position outer						
BPW - NR - NRZVB 12010 K				- 12000		1485
Fitting Position outer						
BPW - NR - NRZVBT 10010				- 10000		1488
Fitting Position outer						
BPW - NR - NRZVBT 10010 C				- 10000		1489
Fitting Position outer						
BPW - NR - NRZVBT 10010 K				- 10000		1490
Fitting Position outer						
BPW - NRD - NRDZF 10010 ECO-MAXX				- 10000		1493
Fitting Position outer						
BPW - NRD - NRDZF 11010 ECO-MAXX				- 11000		1494
Fitting Position outer						
BPW - R - RIZ 11000				- 11000		1549
Fitting Position outer						
BPW - R - RIZ 12000				- 12000		1551
Fitting Position outer						
BPW - R - RIZ 12000-20				- 12000		1552
Fitting Position outer						
BPW - R - RS 10000				- 10000		1556
Fitting Position outer						
BPW - R - RS 10010				- 10000		1557
Fitting Position outer						
BPW - R - RS 10010-17				- 10000		1558
Fitting Position outer						
BPW - R - RS 11010				- 11000		1559
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - R - RS 12010				- 12000		1560
Fitting Position outer						
BPW - R - RSF 10010-17				- 10000		1567
Fitting Position outer						
BPW - R - RSF 10010-17 ECO				- 10000		1568
Fitting Position outer						
BPW - R - RSF 10010-17 ECO-MAXX				- 10000		1569
Fitting Position outer						
BPW - R - RSF 11010				- 11000		1570
Fitting Position outer						
BPW - R - RSF 11010-17				- 11000		1571
Fitting Position outer						
BPW - R - RSF 11010-17 ECO				- 11000		1572
Fitting Position outer						
BPW - R - RSF 11010-20				- 11000		1573
Fitting Position outer						
BPW - R - RSF 12010				- 12000		1574
Fitting Position outer						
BPW - R - RSF 12010-17				- 12000		1575
Fitting Position outer						
BPW - R - RSF 12010-17 ECO				- 12000		1576
Fitting Position outer						
BPW - R - RSF 12010-17 ECO-MAXX				- 12000		1577
Fitting Position outer						
BPW - R - RSF 12010-20				- 12000		1578
Fitting Position outer						
BPW - R - RSF 12010-20 ECO				- 12000		1579
Fitting Position outer						
BPW - R - RSF 12010-30 ECO				- 12000		1580
Fitting Position outer						
BPW - R - RSF 12010-30 ECO-MAXX				- 12000		1581
Fitting Position outer						
BPW - R - RSFH 10010-17				- 10000		1590
Fitting Position outer						
BPW - R - RSM 10008				- 10000		1592
Fitting Position outer						
BPW - R - RSM 10010				- 10000		1593
Fitting Position outer						
BPW - R - RSM 10010-17				- 10000		1594
Fitting Position outer						
BPW - R - RSM 10010-17 ECO				- 10000		1595
Fitting Position outer						
BPW - R - RSM 10010-20				- 10000		1596
Fitting Position outer						
BPW - R - RSM 11010-20				- 11000		1597
Fitting Position outer						
BPW - R - RSM 12010				- 12000		1598
Fitting Position outer						
BPW - R - RSM 12010 ECO				- 12000		1599
Fitting Position outer						
BPW - R - RSM 12010-20				- 12000		1600
Fitting Position outer						
BPW - R - RSM 12010-20 ECO				- 12000		1601
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - SH - SHSM 10010-15 ECO				- 10000		1733
Fitting Position outer						
BPW - SH - SHSM 10010-15 ECO Plus				- 10000		1734
Fitting Position outer						
BPW - SH - SHSM 10010-15 ECO-MAXX				- 10000		1735
Fitting Position outer						
BPW - SH - SHSM 10110-15 ECO				- 10000		1736
Fitting Position outer						
BPW - SH - SHSM 10110-15 ECO Plus				- 10000		1737
Fitting Position outer						
BPW - SH - SHSM 10110-15 ECO-MAXX				- 10000		1738
Fitting Position outer						
BPW - SH - SHSM 12010-16 ECO Plus				- 12000		1739
Fitting Position outer						
BPW - SH - SHSM 12010-16 ECO-MAXX				- 12000		1740
Fitting Position outer						
BPW - SH - SHZ 12010-16 ECO-MAXX				- 12000		1745
Fitting Position outer						
BPW - SH - SHZF 10010-15 ECO				- 10000		1746
Fitting Position outer						
BPW - SH - SHZF 10010-15 ECO Plus				- 10000		1747
Fitting Position outer						
BPW - SH - SHZF 10010-15 ECO-MAXX				- 10000		1748
Fitting Position outer						
BPW - SH - SHZF 10110-15 ECO				- 10000		1749
Fitting Position outer						
BPW - SH - SHZF 10110-15 ECO Plus				- 10000		1750
Fitting Position outer						
BPW - SH - SHZF 10110-15 ECO-MAXX				- 10000		1751
Fitting Position outer						
BPW - SH - SHZF 12010-16 ECO Plus				- 12000		1752
Fitting Position outer						
BPW - SH - SHZF 12010-16 ECO-MAXX				- 12000		1753
Fitting Position outer						
BPW - SH - SHZF 14010-1 ECO-MAXX				- 14000		1754
Fitting Position outer						
BPW - SH - SHZF 14010-15 ECO-MAXX				- 14000		1755
Fitting Position outer						
BPW - SH - SHZF 9010-15 ECO Plus				- 9000		1759
Fitting Position outer						
BPW - SH - SHZM 10010-15 ECO				- 10000		1761
Fitting Position outer						
BPW - SH - SHZM 10010-15 ECO-MAXX				- 10000		1762
Fitting Position outer						
BPW - SH - SHZM 10110-15 ECO				- 10000		1763
Fitting Position outer						
BPW - SH - SHZM 10110-15 ECO Plus				- 10000		1764
Fitting Position outer						
BPW - SH - SHZM 10110-15 ECO-MAXX				- 10000		1765
Fitting Position outer						
BPW - SH - SHZM 12010-16 ECO Plus				- 12000		1766
Fitting Position outer						
BPW - SH - SHZM 12010-16 ECO-MAXX				- 12000		1767
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - SH - SHBF 9010 ECO Plus				- 9000		3954
Fitting Position outer						
BPW - SH - SHSF 8010 ECO Plus				- 9000		3955
Fitting Position outer						
BPW - SH - SHSM 9010 ECO Plus				- 9000		3958
Fitting Position outer						
BPW - SH - SHSM 9010-15 ECO Plus				- 9000		3959
Fitting Position outer						
BPW - SH - SHZF 9010 ECO Plus				- 9000		3960
Fitting Position outer						
BPW - SH - SHZM 9010-15 ECO Plus				- 9000		3961
Fitting Position outer						
BPW - SH - SHBF 9010 ECO Plus2				- 9000		4222
Fitting Position outer						
BPW - SH - SHSF 9010 ECO Plus2				- 9000		4223
Fitting Position outer						
BPW - SH - SHSF 9010-15 ECO Plus2				- 9000		4224
Fitting Position outer						
BPW - SH - SHSM 9010 ECO Plus2				- 9000		4225
Fitting Position outer						
BPW - SH - SHSM 9010-15 ECO Plus2				- 9000		4226
Fitting Position outer						
BPW - SH - SHZF 9010 ECO Plus2				- 9000		4229
Fitting Position outer						
BPW - SH - SHZF 9010-15 ECO Plus2				- 9000		4230
Fitting Position outer						
BPW - SH - SHZM 9010-15 ECO Plus2				- 9000		4231
Fitting Position outer						
BPW - SKH - SKHBF 9010 ECO Plus				- 9000		1698
Fitting Position outer						
BPW - SKH - SKHBF 9010-15 ECO Plus				- 9000		1700
Fitting Position outer						
BPW - SKH - SKHBFHLL 9010 ECO Plus				- 9000		1702
Fitting Position outer						
BPW - SKH - SKHBM 9010 ECO Plus				- 9000		1704
Fitting Position outer						
BPW - SKH - SKHBM 9010-15 ECO Plus				- 9000		1705
Fitting Position outer						
BPW - SKH - SKHBMHLL 9010 ECO Plus				- 9000		1707
Fitting Position outer						
BPW - SKH - SKHSF 10008-15 ECO Plus				- 10000		1709
Fitting Position outer						
BPW - SKH - SKHSF 10008-15 ECO-MAXX				- 10000		1710
Fitting Position outer						
BPW - SKH - SKHSF 10010-15 ECO Plus				- 10000		1711
Fitting Position outer						
BPW - SKH - SKHSF 10010-15 ECO-MAXX				- 10000		1712
Fitting Position outer						
BPW - SKH - SKHSF 9008 ECO Plus				- 9000		1715
Fitting Position outer						
BPW - SKH - SKHSF 9008-15 ECO Plus				- 9000		1718
Fitting Position outer						
BPW - SKH - SKHSF 9010 ECO Plus				- 9000		1719
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - SKH - SKHSF 9010-15 ECO Plus				- 9000		1721
Fitting Position outer						
BPW - SKH - SKH 9008				- 9000		1770
Fitting Position outer						
BPW - SKH - SKH 9010				- 9000		1771
Fitting Position outer						
BPW - SKH - SKHB 9010				- 9000		1772
Fitting Position outer						
BPW - SKH - SKHSF 9010-15 ECO Plus				- 9000		1773
Fitting Position outer						
BPW - SKH - SKHSFHLL 9010 ECO Plus				- 9000		1777
Fitting Position outer						
BPW - SKH - SKHSM 10010-15 ECO Plus				- 10000		1779
Fitting Position outer						
BPW - SKH - SKHSM 10010-15 ECO-MAXX				- 10000		1780
Fitting Position outer						
BPW - SKH - SKHSM 9008-15 ECO Plus				- 9000		1782
Fitting Position outer						
BPW - SKH - SKHSM 9010 ECO Plus				- 9000		1784
Fitting Position outer						
BPW - SKH - SKHSM 9010-15 ECO Plus				- 9000		1786
Fitting Position outer						
BPW - SKH - SKHSMHLL 9010 ECO Plus				- 9000		1792
Fitting Position outer						
BPW - SKH - SKHZF 10008-15 ECO Plus				- 10000		1794
Fitting Position outer						
BPW - SKH - SKHZF 10008-15 ECO-MAXX				- 10000		1795
Fitting Position outer						
BPW - SKH - SKHZF 10010-15 ECO Plus				- 10000		1796
Fitting Position outer						
BPW - SKH - SKHZF 10010-15 ECO-MAXX				- 10000		1797
Fitting Position outer						
BPW - SKH - SKHZF 9008 ECO Plus				- 9000		1798
Fitting Position outer						
BPW - SKH - SKHZF 9008-15 ECO Plus				- 9000		1800
Fitting Position outer						
BPW - SKH - SKHZF 9010 ECO Plus				- 9000		1802
Fitting Position outer						
BPW - SKH - SKHZF 9010-15 ECO Plus				- 9000		1804
Fitting Position outer						
BPW - SKH - SKHZM 10008-15 ECO-MAXX				- 10000		1806
Fitting Position outer						
BPW - SKH - SKHZM 10010-15 ECO-MAXX				- 10000		1807
Fitting Position outer						
BPW - SKH - SHZF 9010 ECO Plus				- 9000		3962
Fitting Position outer						
BPW - SKH - SKHSFHLL 9008 ECO Plus				- 9000		3963
Fitting Position outer						
BPW - SKH - SKHSF 8008 ECO Plus				- 8000		4054
Fitting Position outer						
BPW - SKH - SKHSF 8010 ECO Plus				- 8000		4055
Fitting Position outer						
BPW - SKH - SKHSM 9008 ECO Plus				- 9000		4056
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
BPW - SKH - SKHZM 9008 ECO Plus				- 9000		4057
Fitting Position outer						
BPW - SKH - SKHZM 9008-15 ECO Plus				- 9000		4066
Fitting Position outer						
BPW - SKH - SKHZF 9010 ECO Plus2				- 9000		4228
Fitting Position outer						
BPW - SKH - SKHBF 9010 ECO Plus2				- 9000		4232
Fitting Position outer						
BPW - SKH - SKHBF 9010-15 ECO Plus2				- 9000		4233
Fitting Position outer						
BPW - SKH - SKHBFHLL 9010 ECO Plus2				- 9000		4234
Fitting Position outer						
BPW - SKH - SKHBM 9010 ECO Plus2				- 9000		4235
Fitting Position outer						
BPW - SKH - SKHBM 9010-15 ECO Plus2				- 9000		4236
Fitting Position outer						
BPW - SKH - SKHBMHLL 9010 ECO Plus2				- 9000		4237
Fitting Position outer						
BPW - SKH - SKHSF 9008 ECO Plus2				- 9000		4238
Fitting Position outer						
BPW - SKH - SKHSF 9008-15 ECO Plus2				- 9000		4239
Fitting Position outer						
BPW - SKH - SKHSF 9010 ECO Plus2				- 9000		4240
Fitting Position outer						
BPW - SKH - SKHSF 9010-15 ECO Plus2				- 9000		4241
Fitting Position outer						
BPW - SKH - SKHSFHLL 9008 ECO Plus2				- 9000		4242
Fitting Position outer						
BPW - SKH - SKHSFHLL 9010 ECO Plus2				- 9000		4243
Fitting Position outer						
BPW - SKH - SKHSM 9008 ECO Plus2				- 9000		4244
Fitting Position outer						
BPW - SKH - SKHSM 9008-15 ECO Plus2				- 9000		4245
Fitting Position outer						
BPW - SKH - SKHSM 9010 ECO Plus2				- 9000		4246
Fitting Position outer						
BPW - SKH - SKHSM 9010-15 ECO Plus2				- 9000		4247
Fitting Position outer						
BPW - SKH - SKHSMHLL 9010 ECO Plus2				- 9000		4248
Fitting Position outer						
BPW - SKH - SKHZF 9008 ECO Plus2				- 9000		4249
Fitting Position outer						
BPW - SKH - SKHZF 9008-15 ECO Plus2				- 9000		4250
Fitting Position outer						
BPW - SKH - SKHZF 9010-15 ECO Plus2				- 9000		4253
Fitting Position outer						
BPW - SKH - SKHZM 9008 ECO Plus2				- 9000		4254
Fitting Position outer						
BPW - SKH - SKHZM 9008-15 ECO Plus2				- 9000		4255
Fitting Position outer						
BPW - ZR - ZRZ 10010				- 10000		1844
Fitting Position outer						
GIGANT - Protec - DH6 10008 3745				- 10000		3389
Fitting Position outer						

Description	Axle Version	Axle Design	Wheel suspension	Axle Load [kg]	Brake type	TecDoc axle number
GIGANT - Protec - GVH5 10008 3620				- 10000		3462
Fitting Position outer						
GIGANT - Protec - GVH5 10010 3020				- 10000		3463
Fitting Position outer						
GIGANT - Protec - GVH5 10010 3620				- 10000		3464
Fitting Position outer						
GIGANT - Protec - DH6 10010 4345				- 10000		4282
Fitting Position outer						
MERITOR - TA - TA				- 13000		3686
Fitting Position outer						
MERITOR - TA - TA				- 13000		3691
Fitting Position outer						
MERITOR - TA - TA				- 9000		4077
Fitting Position outer						
MERITOR - TA - TA				- 9000		4078
Fitting Position outer						
MERITOR - TA - TA				- 13000		4079
Fitting Position outer						
MERITOR - TA - TA				- 9000		4080
Fitting Position outer						
MERITOR - TA - TA				- 13000		4081
Fitting Position outer						
MERITOR - TA - TA				- 13000		4082
Fitting Position outer						
MERITOR - TM - TM						3688
Fitting Position outer						
MERITOR - TM - TM						3693
Fitting Position outer						
MERITOR - TM - TM						3714
Fitting Position outer						
MERITOR - TM - TM						3715
Fitting Position outer						

OE information

Manufacturer	OE number	Reference information
BPW	02.6407.65.00	
BPW	02.6407.67.00	
BPW	02.6410.22.00	
DANA	005104203	
EVOBUS	003 981 37 05	
EVOBUS	003 981 74 05	
FIAT	7174946	
GIGANT	10500558	
HENDRICKSON	502281	
IVECO	7174946	
KÄSSBOHRER	6.691.314.000	
MAN	06.32489.0006	
MAN	06.32489.0046	
MAN	81.44050.0075	
MAN	81.93420.0080	
MERCEDES-BENZ	001 980 09 02	
MERCEDES-BENZ	003 981 37 05	
MERCEDES-BENZ	003 981 74 05	
MERCEDES-BENZ	006 981 63 05	
MERCEDES-BENZ	008 981 00 05	
MERCEDES-BENZ	384 981 72 05	
MERITOR	99041045	

Manufacturer	OE number	Reference information
MERITOR	99041045B	
MERITOR	99041045S	
RENAULT	5000437791	
RENAULT	5000873122	
RENAULT	5010136769	
RENAULT	5010368899	
RENAULT	5010368900	
RENAULT	5010439065	
RENAULT TRUCKS	50 00 437 786	
RENAULT TRUCKS	50 00 437 791	
RENAULT TRUCKS	50 00 873 122	
RENAULT TRUCKS	50 10 067 672	
RENAULT TRUCKS	50 10 136 769	
RENAULT TRUCKS	50 10 368 899	
RENAULT TRUCKS	50 10 368 900	
RENAULT TRUCKS	50 10 439 065	
SAF	4 200 0060 00	
SCHMITZ CARGOBULL	10278	
SCHMITZ CARGOBULL	15052	
TRAILOR	6502196Z	
VOLVO	184672	
YORK	502281	